
# KALLAX









### English

## **WARNING**

Children have died from furniture tipover.To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.


NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.


ALWAYS secure your television with an anchor device.


#### English


Read and follow each step of the instruction carefully.


AA-2582028-1





















































# 



# **15**

