




KILBERGET



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.




NEVER open more than one drawer at a time.






DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.





109048

2x




10087223

2x




109049

1x




100823

2x




10102070

1x




106989

1x




370173


1



8x



22x




30x




4x




18x



4x




22x




1x

2




12x




12x




6x



6x




6x




24x



18x



3x




1




10x

101345




2




6x


118331




3




4




5




6





7





8























16




17







18




19




20






21





22



23




24



25

×

×






www.IKEA.com/secure-it




www.IKEA.cn/secure-it



English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C



Ø 3 mm
(1/8")





1







2











26











28








28







3x




30




4x




31




2x




32




33




34




35




36




37




38




39



40



41



42

