





KILBERGET



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.







NEVER open more than one drawer at a time.






DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.






109572

2x




10087223

2x




10102070

2x




370172

1




115980

2x



118331

16x



100481

4x



105811

8x




146114

36x




119030

20x




153552

6x




101345

22x



101339

2x




10093081

8x




10093082

8x



151706


6x




151705

6x

2




24x




24x




6x



12x




6x




48x



36x






6x







6x

2x


1




2




3




4




5




6





7




8




9




10




11




12




13






14




15







17




18




19




20




21




22




23




24




25




26




27





28







29




30




31

×

×






www.IKEA.com/secure-it




www.IKEA.cn/secure-it



English


The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

A




Ø 8 mm
(5/16")


1




2



3




B




Ø 8 mm
(5/16")


1




2



3




C






Ø 3 mm
(1/8")

1





2








32




10102070





33









34






34







35




36




37




38




39




40




41




42



43



44



45

