


LASTARE



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.



NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.




NEVER open more than one drawer at a time.




Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.



	A	B	C
 www.IKEA.com/secure-it			
	$\text{Ø } 8 \text{ mm (5/16")}$ 	$\text{Ø } 8 \text{ mm (5/16")}$ 	$\text{Ø } 3 \text{ mm (1/8")}$ 






118331

8x



101345

8x



10124042

2x



109538

2x




100359

2x



119252

8x




10095326

10x



10095315

10x




10127224

4x



101449

4x




10005905

2x




10127151

2x




10122594

1x




10122530


1x




2x




2x




2x





2x





2x




2x




1





2







3




4




5




6




7




8




9





10







11






12









13





14






12







13





14





15







16






17







15



16



17






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



18

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

A

Ø 8 mm (5/16")

1

70 mm (2 3/4")

2

24

B

Ø 8 mm (5/16")

1

≈ 30 mm (≈ 1 1/4")

2

25


C

Ø 3 mm (1/8")


1

≈ 30 mm (≈ 1 1/4")



27





19




20








19






20












19











21








21









22







1





2






two two



23



8x

