


MILSBO



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.



NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English

Read and follow each step of the instruction carefully.





4x




12x




16x




1x




2x




2x



4x



2x




8x




4x




4x




2x




1x




2x




2x




1x




1




2






3




4




5





6





7





8




9







10





11




12













16





17





18




























25




26





28



29

