





PLATSA



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English

Read and follow each step of the instruction carefully.






108736

4x




152059

4x



151705

8x




151706

8x




146113

2x




10005905

2x




126916

2x




150689

2x



150688



2x




10090922

1x


1




2




3






4





5





6







7




8









9










10







4x



4x

