





PLATSA



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.


NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.






108736

4x



151705

8x



151706

8x




152059

4x




146113

2x




150689

2x




150688

2x




10005905

2x



126916



2x




10090922

1x


1




2




3






4





5






6








7









10

