



PLATSA



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.






150689

2x



150688

2x




10005905

2x




126916

2x




151705

8x




151706

8x



146113




4x




10090922

2x


1




2




3




4







5




6











↕
7







10

