


RÅDMANSÖ



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.






10115683


1




1x




12x



4x




4x




4x




12x



20x




20x




22x




26x




4x



1x




2x




22x

2




159553

16x



119976

1x




10109447

1x



117434

16x




108528

4x




10047245

24x




10094662

4x




190459

1x




10094656

2x





10094681


2x




10040242

6x







1




2




3



4




5





4x




10120564




6




7




8




9




10




11





12




13




14




15




16




17




18




19




20



21



22






www.IKEA.com/secure-it



www.IKEA.cn/secure-it




23

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C




Ø 3 mm
(1/8")




1




2




24





25




26




27




28




29




30




31





32






33




34




35




36




37










38




39




40



41




42






43

6x




44








46



47







50

