


STOCKHOLM

2025



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

Always anchor your furniture with an anti-tip device.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.






English


Read and follow each step of the instruction carefully.






1








3




4







7




8




9




10




11




12




13




14




15






16







17




18




19




20




21




22




23




24



25



26



27

