


SUNNERSTA



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.



NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.







8x




4x



2x




2x




1x


1




2




3




4






5



6






7






Hand icon 3 mm
(1/8")

7




Hand icon 10 mm
(3/8")

7




Hand icon 15 mm
(5/8")


8



9



10



11

