


TROFAST



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.



NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

NEVER open more than one drawer at a time.


Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.



28x




52x




24x




1x




2x




8x



1x




1x




24x


1




2x




2




8x




3




4




5




6




7




8




9




10




11




12




13




14




15





16





17









20

