# TROTTEN









English

#### **WARNING**

Children have died from furniture tipover.To reduce the risk of furniture tipover:

Always anchor your furniture with an anti-tip device.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

2 AA-2580741-2



























































