



VIHALS



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.





NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.






A




145718
159553
10096669

8x



130449

8x




119030
117434
131361

16x




146114

12x



10040242

2x




10071494
10099810
10106969


2x




1




12x



2



4x




8x




12x




8x




4x




4x




2x




2x




8x



1x









4x








6x













1




2






3




4




10061178
10100254
10107020




5




6




7




8




9




10







12




13







14







15



16








18

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C




Ø 3 mm
(1/8")



1






2





3











21




22










25




26







27




28




29




30




31




32




33




34



35



36



37

