



Buying guide

# ENEBY

Bluetooth speaker



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by IKEA of Sweden AB is under license. Other trademarks and trade names are those of their respective owners.



## Speakers to feel at home, where ever you are.

Our Bluetooth speakers are designed to fit perfectly with your home's interior and furniture and they have a clear and powerful sound. ENEBY 30 fits in our KALLAX wall cabinet, while ENEBY 20 can be completed with a battery so that you can place it wherever you don't have a wall socket. With ENEBY Portable you can listen to great music on the go. And ENEBY Built-in can fit in most pieces of furniture and fits perfectly in the pre-cut hole of the MICKE desk.



# Good to know

## Why Bluetooth?

Bluetooth speakers are great for a portable music experience in your home or outside. You connect to the speaker from your phone or from other Bluetooth enabled devices. By adding batteries to the speakers, they become truly portable and you can enjoy your music anywhere.


## Batteries

The rechargeable batteries for our Bluetooth speakers are sold separately. If you choose to use the speakers with the included power cord, you can always add batteries at a later time. Rechargeable batteries are better for your wallet and for the environment, and you can easily replace the batteries after the end of their lifespan.

## Recycling

All rechargeable batteries have a limited number of charge cycles. It might be time for new batteries if you need to charge your device more frequently. Just make sure to recycle the old ones.


# All parts and prices



### ENEBY bluetooth speaker 30×30 cm.

You get a clear and powerful sound experience wherever you place it – either standing or mounted on the wall. Choose the soft fabric front or a minimalist look with parts of the speaker exposed.

Black	704.924.19
White	604.924.29



### ENEBY bluetooth speaker 20×20 cm.

You get a clear and powerful sound experience wherever you place it – either standing or mounted on the wall. Choose the soft fabric front or a minimalist look with parts of the speaker exposed. Recharges ENEBY battery pack inside of the speaker with the included power cable, battery pack sold separately.

Black	504.923.97
White	804.924.09



**ENEBY battery pack.** You can bring the music to where you are and your friends are. The battery powers your ENEBY 20x20 cm speaker when there are no outlets to be found nearby.

003.575.37



**ENEBY speaker wall bracket.** ENEBY wall bracket helps to free up valuable surface space and puts your favourite music at ear level. The bracket makes the speaker stand out from the wall so it becomes a design element in the room.

203.576.21



**ENEBY portable bluetooth speaker 15×7.5 cm.** With this portable speaker you can enjoy music anywhere at home – and bring it along wherever you go since the speaker is powered by batteries. Small and practical – but big when it comes to sound! Recharges IKEA LADDA 900 rechargeable batteries inside of the speaker with the included LILLHULT usb cable, batteries sold separately.

Black	004.762.10
White	904.762.15



**LADDA rechargeable battery.** HR03 AAA 1.2V, 4-p, 900mAh. Reduce waste and save money by recharging your batteries. Charging and re-using batteries is a good choice for the environment and practical too since you always have batteries at hand when you need them.

905.098.19

# How to choose

	Wattage	Microphone	Aux-in	Battery play time*	Volume synced with Bluetooth device	Charging via USB
ENEBY Portable	3	●	●	15 hours	●	●
ENEBY 20	20	—	●	8 to 10 hours	—	—
ENEBY 30	42	—	●	—	—	—

\* playing music at 50% volume