

Bathroom showers

Design

H Preutz/N Karlsson

Care instructions


Clean with a soft cloth dampened with water and a mild washing-up detergent or soap. Never use scouring powder, steel wool or a detergent that is calcium dissolving, sour or contains alcohol or an abrasive. Rinse with water and dry/polish with a clean dry cloth. To remove larger lime scale deposits – use diluted, ordinary white vinegar and rinse with water.

Good to know

Wall fittings are provided with the product. If you are uncertain about the installation, contact a professional. The installation shall be made in accordance with valid local building and plumbing regulations.

Safety

The thermostatic faucet is preset to a safety stop temperature of 38°C. Since operating conditions in each supply system varies, it might be necessary to calibrate the mixer according to the service and installation instructions.



10

All thermostatic faucets have a 10-year limited warranty. Read more in the warranty brochure.

3

All riser rails, head/hand showers, hoses, parking bracket, and shower shelves have a 3-year limited warranty. Read more in the warranty brochure.

Everyone deserves a refreshing shower

The IKEA showers are fully coordinated, with everything you need for a great shower experience: thermostatic faucets, head and hand showers with different spray functions and bathroom accessories, all in the same family. All IKEA showers are equipped with water and energy-efficient shower heads and hand showers. This is achieved by having a flow regulator, which reduces the water flow. You'll save up to 30% water and energy compared to a shower without a flow regulator. Everyone deserves a refreshing shower experience every day. And what can be more revitalising than knowing you can save water (and money on your water and energy bills) at the same time? Just pick and choose the shower function you need in your bathroom.

This is a reference guide created to better assist customers when purchasing products. While a high level of accuracy has been sought in its preparation, we cannot guarantee that there are no errors or omissions nor will we be bound by them. Availability may vary by store and prices are subject to change. Please see an IKEA co-worker or visit www.IKEA.ca for more information.



How to choose

1. Here are a few practical steps to help you choose the right product for a great shower experience. Before the purchase consider what shower needs you have in your bathroom. Do you need to refresh an existing shower set? Then you may choose a riser rail with hand shower kit and wall outlet. All IKEA riser rail kits are compatible with any thermostatic faucet of another manufacturer. The shower kits come in 3 different families – VALLAMOSSE, BROGRUND and VOXNAN just pick the one that suits your style and bathroom best.
2. In case if you want to revitalize your existing shower you can choose to change the hand shower or the shower hose. IKEA shower series offer a wide variety of head and hand showers that come with different spray functions. You can choose between 1, 3 and 5 spray function heads. The head/hand shower with full spray function gives a wide and even coverage for a relaxing shower experience. The mesh spray function boosts the force of the water spray which is perfect for rinsing thick hair. The massage spray function varies the water flow from soft to hard for an invigorating experience that takes away the tension. The mist spray function produces fine droplets of water that feel gentle, soft and relaxing. On 3-spray head shower you can choose between full spray or mesh spray or you can combine the two, giving you the best of both worlds. With the 5-spray head/hand shower you can alternate between full, mist or massage sprays, or choose your favourite combination of full/mist or full/massage, giving you even more alternatives for a relaxing shower.
3. Finally, if you are planning to update your entire shower area then you can choose one of the IKEA thermostatic shower sets that includes all the functions you need for a destressing and relaxing shower experience. IKEA shower sets include thermostatic shower and bath/shower faucets so they are a perfect fit both for a bath tub and shower walls. You can complete your new shower with mixer taps and towel accessories from the same product family for a full style coordination of your bathroom. BROGRUND and VOXNAN series feature a complete range of showers, mixer taps and bathroom accessories that will make your bathroom uniquely you.

All parts

All thermostatic shower faucets have 10-year warranty and all the riser rails, head/hand showers, hoses, parking bracket and shower shelves have a 3-year warranty.




BROGRUND shower set with thermostatic faucet. Shower head Ø90 mm (3½"), thermostatic faucet Ø175 mm (7").

Chrome-plated finish 103.426.25



BROGRUND bath/shower set with thermostatic faucet. Shower head Ø90 mm (3½"), thermostatic faucet Ø175 mm (7"), spout depth 166 mm (6½").

Chrome-plated finish 903.426.26



BROGRUND riser rail with hand shower and wall outlet. Hand shower Ø90 mm (3½"), riser rail height 651 mm (25½"), length of hose 1500 mm (59").

Chrome plated finish 503.426.28




BROGRUND 5-spray shower head. Shower head Ø100 mm (4").

Chrome-plated finish 003.517.95



BROGRUND 5-spray hand shower. Hand shower Ø100 mm (4").

Chrome-plated finish 603.517.97




BROGRUND shower shelf, width 25 cm (9¾"), depth 12 cm (4¾"), height 4 cm (1½").

Chrome-plated finish 903.285.26




VOXNAN shower set with thermostatic faucet. Shower head Ø90 mm (3½"), thermostatic faucet Ø175 mm (7").

Chrome-plated finish 803.426.22



VOXNAN bath/shower set with thermostatic faucet. Shower head Ø90 mm (3½"), thermostatic faucet Ø175 mm (7"), spout depth 166 mm (6½").

Chrome-plated finish 003.426.21




VOXNAN riser rail with hand shower and wall outlet. Hand shower Ø90 mm (3½"), riser rail height 680 mm (26¾"), length of hose 1500 mm (59").

Chrome plated finish 603.426.23



VOXNAN shower shelf, width 25 cm (9¾"), depth 13 cm (5"), height 6 cm (2¼").

Chrome-plated finish 703.285.89



VALLAMOSSE riser rail with hand shower and wall outlet. Hand shower Ø79 mm (3¼"), riser rail height 623 mm (24½"), length of hose 1500 mm (59").

Chrome plated finish 703.519.33




LILLREVET single-spray hand shower. Hand shower Ø79 mm (3¼").

White 503.426.33



LILLREVET shower hose, length 1500 mm (59").

White 004.084.38



KOLSJÖN shower hose, length 1500 mm (59").


Chrome-plated finish 803.518.00




KOLSJÖN hand shower parking bracket, width 5 cm (2"), depth 5 cm (2").

Chrome-plated finish 303.905.02


Towel accessories




BROGRUND towel rail, length 67 cm (26½"), depth 13 cm (5").
Stainless steel 303.285.34



BROGRUND wall shelf with towel rail, width 67 cm (26½"), depth 27 cm (10¾").
Stainless steel 703.339.82



BROGRUND hanger for door, width 29 cm (11½"), height 14 cm (5½").
Stainless steel 203.285.44



BROGRUND corner wall shelf unit, width 19 cm (7½"), depth 19 cm (7½"), height 58 cm (22¾").
Stainless steel 304.089.79



BROGRUND hook, 2 pack.
Stainless steel 205.246.77




VOXNAN towel rail, length 67 cm (24¾"), depth 13 cm (5").
Chrome plated finish 603.285.99



VOXNAN wall shelf with towel rail, width 68 cm (26¾"), depth 28 cm (11").
Chrome plated finish 103.285.87



VOXNAN towel holder 3 bars, extendable bars 45–65 cm (17¾–25½").
Stainless steel / chrome-plated zinc 204.345.49



VOXNAN hanger for door, width 36 cm (14"), height 12 cm (4½").
Chrome plated finish 803.285.79



VOXNAN towel hanger, height 16 cm (6¼").
Chrome plated finish 403.289.82

Services

We offer a range of services to help you with everything from putting it together to getting it home. Of course, the more you do yourself, the lower the price will be. And the more we do for you, the more you can sit back and relax!



Delivery service

Can't take your furniture with you?
We'll bring it to your home or workplace.



Click and Collect

Your online purchases can be ready for pick-up on a day that's convenient for you. Have access to all items available to purchase online at IKEA.ca. It's easy:

1. Buy your items online
2. Pre-select a date to collect your order
3. Pick-up your purchase at an IKEA store near you.



It's ok to change your mind

You have 365 days to return your purchase. Keep your receipt safe to make returns easier. You're free to change your mind. Return unused items in their original packaging within 365 days together with proof of purchase for a full refund.