

# ENEBY

## Bluetooth speaker



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by IKEA of Sweden AB is under license. Other trademarks and trade names are those of their respective owners.



### Speakers to feel at home, where ever you are.

Our Bluetooth® speakers are designed to fit perfectly with your home's interior and furniture and they have a clear and powerful sound. ENEBY 30 fits in our KALLAX wall cabinet, while ENEBY 20 can be completed with a battery so that you can place it wherever you don't have a wall socket. With ENEBY Portable you can listen to great music on the go. And ENEBY Built-in can fit in most pieces of furniture and fits perfectly in the pre-cut hole of the MICKE desk.

This is a reference guide created to better assist customers when purchasing products. While a high level of accuracy has been sought in its preparation, we cannot guarantee that there are no errors or omissions nor will we be bound by them. Availability may vary by store and prices are subject to change. Please see an IKEA co-worker or visit [www.IKEA.ca](http://www.IKEA.ca) for more information.



# Good to know

## Why Bluetooth®?

Bluetooth® speakers are great for a portable music experience in your home or outside. You connect to the speaker from your phone or from other Bluetooth® enabled devices. By adding batteries to the speakers, they become truly portable and you can enjoy your music anywhere.

## Recycling

All rechargeable batteries have a limited number of charge cycles. It might be time for new batteries if you need to charge your device more frequently. Just make sure to recycle the old ones.

## Batteries

The rechargeable batteries for our Bluetooth® speakers are sold separately. If you choose to use the speakers with the included power cord, you can always add batteries at a later time.

Rechargeable batteries are better for your wallet and for the environment, and you can easily replace the batteries after the end of their lifespan.

# All parts



**ENEBY bluetooth speaker 30×30 cm.** You get a clear and powerful sound experience wherever you place it — either standing or mounted on the wall. Choose the soft fabric front or a minimalist look with parts of the speaker exposed.

Black	404.924.25
White	304.924.35



**ENEBY bluetooth speaker 20×20 cm.** You get a clear and powerful sound experience wherever you place it — either standing or mounted on the wall. Choose the soft fabric front or a minimalist look with parts of the speaker exposed. Recharges ENEBY battery pack inside of the speaker with the included power cable, battery pack sold separately.

Black	104.924.03
White	504.924.15



**ENEBY battery pack.** You can bring the music to where you are and your friends are. The battery powers your ENEBY 20×20 cm speaker when there are no outlets to be found nearby.

204.142.64



**ENEBY speaker stand.** You get a good sound experience because the stand raises your ENEBY speaker from the surface and angles it, so the sound is directed towards you.

Black	403.575.78
-------	------------




**ENEBY speaker wall bracket.** ENEBY wall bracket helps to free up valuable surface space and puts your favourite music at ear level. The bracket makes the speaker stand out from the wall so it becomes a design element in the room.

603.576.19



**ENEBY portable bluetooth speaker 15×7.5 cm.** With this portable speaker you can enjoy music anywhere at home — and bring it along wherever you go since the speaker is powered by batteries. Small and practical — but big when it comes to sound! Recharges IKEA LADDA AAA 900mAh rechargeable batteries inside of the speaker with the included LILLHULT usb cable, AAA batteries sold separately.

Black	204.014.07
-------	------------



**LADDA rechargeable battery.** HR03 AAA 1.2V, 4-p, 750mAh. Reduce waste and save money by recharging your batteries. Charging and re-using batteries is a good choice for the environment and practical too since you always have batteries at hand when you need them.

905.098.19

# How to choose

	Wattage	Microphone	Aux-in	Battery play time *	Volume synced with Bluetooth® device	Charging via USB
<b>ENEBY Portable</b>	3	●	●	15 hours	●	●
<b>ENEBY 20</b>	20	—	●	8 to 10 hours	—	—
<b>ENEBY 30</b>	42	—	●	—	—	—

\* Playing music at 50% volume.