





UTRUSTA




Design and Quality
IKEA of Sweden



109053

4x



109535

14x



109049

4x




126887

8x




114678

2x




107091

1x




10081285


2x




1x




1x




2x



1x




1x




1x

1x




10082108

1x




10082109

1x



10079445



1x




10082116

1x


1




2




3





4




5











6




7





8







9




10




11




12




13




14












15







16











**English**

Wipe clean with a soft cloth dampened in water and a mild non-abrasive washing-up detergent or soap, if necessary. Wipe dry with a clean cloth.

Français

Nettoyer à l'aide d'un chiffon doux imbibé d'eau et, si besoin, d'un détergent non abrasif ou de savon. Essuyer avec un chiffon propre.

Español

Limpiar con un paño suave humedecido en una solución de agua y un detergente neutro o jabón delicado, si fuese necesario. Secar con un paño limpio.

