






STENABY FRILLESBO SPJUTBO



Design and Quality
IKEA of Sweden



GALEGO

Atención! Antes de comezar coa instalación, lea as instrucións de montaxe no manual de uso.

EUSKARA

Kontuz! Instalazioari ekin aurretik, irakurri Erabiltzailearen eskuliburuko segurtasun-informazioa.

CATALÀ

Avís! Llegiu la informació de seguretat al Manual d'usuari abans de començar la instal·lació.



GALEGO








Para ver o diagrama de instalación estándar (instalación nunha cociña que non sexa de IKEA), diríxase á última páxina.


EUSKARA

Instalazio arrunta bada (IKEA-rena ez den sukalde batean), ikus azkeneko orriko diagrama.

CATALÀ

Per veure l'esquema d'instal·lació estàndard (instal·lació en una cuina no IKEA), vegeu l'última pàgina.







2x



2x




1x










1x








2x













1





2





3




4







5








1









1




2







3




4



7



8



9

