








RÅDMANSÖ




Design and Quality
IKEA of Sweden





1







2




3






4




5





6







7




8




9




10




11




12




13





14




15









2x



12x




4x




4x




12x



2x



20x




20x




22x




2x




2x





1x



2x



2x



**Español**

Si tienes que sustituir herrajes dañados o te falta alguno, ponte en contacto con tu tienda IKEA más cercana.

Català

Si falten ferramentes o n'hi ha alguna de trencada, posa't en contacte amb la teva botiga IKEA per canviar-les.

Euskara

Jarri harremanetan zure tokiko IKEA dendarekin falta diren edo hondatutako osagarriak ordezkatzeko.

Galego

Se tes que substituír ferraxes danadas o che falta algunha, contacta coa túa tenda IKEA máis próxima.