Buying guide

Bathroom showers

Design

H Preutz/N Karlsson

Care

SHOWERS: Clean with a soft cloth dampened with water and a mild washing-up detergent or soap. Never use scouring powder, steel wool or a detergent that is calcium- dissolving, sour or contains alcohol or an abrasive. Rinse with water and dry/polish with a clean dry cloth. To remove larger limescale deposits – use diluted, ordinary white vinegar and rinse with water

SHOWER DOOR/ SCREEN:

Remove limescale stains using a small amount of limedissolving solution, e.g. vinegar or lemon juice. Then clean again with a damp cloth. Do not use scouring-powder, steel wool, hard or sharp tools which can scratch the surface.

Good to know

Wall fittings are provided with the product. If you are uncertain about the installation, contact a professional. The installation shall be made in accordance with valid local building and plumbing regulations.


Safety

The thermostatic mixer is pre-set to a safety stop temperature of 38°C. Since operating conditions in each supply system varies, it might be necessary to calibrate the mixer according to the service and installation instructions.





Read more in the guarantee brochure.




Everyone deserves a refreshing shower

The IKEA showers are fully coordinated, with everything you need for a great shower experience: thermostatic mixers with anti-scald feature, head and hand showers with different spray functions and bathroom accessories, all in the same family. Complete your bathroom with shower door and screen to create the perfect shower area. All IKEA showers are equipped with water and energy-efficient shower heads and hand showers. This is achieved by having a flow regulator, which reduces the water flow. You'll save water and energy compared to a shower without a flow regulator. Everyone deserves a refreshing shower experience every day. And what can be more revitalising than knowing you can save water (and money on your water and energy bills) at the same time? Just pick and choose the shower function you need in your bathroom.



How to build



- 1. Here are a few practical steps to help you choose the right product for a great shower experience. Before the purchase consider what shower needs you have in your bathroom. Do you need to refresh an existing shower set? Then you may choose either a riser rail with hand shower kit or a head/hand shower kit with diverter. All IKEA shower kits are compatible with any shower mixer of another manufacturer. The shower series come in 3 different families VALLAMOSSE, BROGRUND and VOXNAN just pick the one that suits your style and bathroom best.
- 2. If you plan to change your shower mixer you can choose between a thermostatic shower and a bath/shower mixer depending on the shower solution in your bathroom. The bath/shower mixers work well both with bath tubs as well as with shower walls. VALLAMOSSE, BROGRUND and VOXNAN shower series offer a wide range of thermostatic mixers that will suit your needs perfectly. All our mixers are fitted with integrated shelves, 38°C safety button and most importantly all our mixer bars come with anti-scald technology and thanks to "cold touch" feature our mixers are safe to touch during use even for the smallest ones in the family.
- 3. In case if you want to revitilise your existing shower you can choose to change the hand shower or the shower hose. IKEA shower series offer a wide variety of hand showers that come with different spray functions. You can choose between 1,3 and 5 spray function heads. The hand shower with full spray function gives a wide and even coverage for a relaxing shower experience. The mesh spray function boosts the force of the water spray which is perfect for rinsing thick hair. The massage spray function varies the water flow from

- soft to hard for an invigorating experience that takes away the tension. The mist spray function produces fine droplets of water that feel gentle, soft and relaxing. On 3-spray hand shower you can choose between full spray or mesh spray or you can combine the two, giving you the best of both worlds. With the 5-spray hand shower you can choose between full, mist or massage sprays, or choose your favorite combination of full/mist or full/massage, giving you even more alternatives for a relaxing shower.
- 4. If you are planning to update your entire shower area then you can choose one of the IKEA thermostatic shower sets that includes all the functions you need for a destressing and relaxing shower experience.
- 5. If you want to add a shower door and/or shower screens this can be done in many different ways. Put together a shower door and a shower screen and you have created a complete shower enclosure. Or just add a shower screen instead of using a shower curtain. You choose!
- 6. You can complete your new shower with mixer taps and towel accessories from the same product family for a full style coordination of your bathroom. BROGRUND and VOXNAN series feature a complete range of showers, mixer taps and bathroom accessories that will make your bathroom uniquely you.

All parts

All thermostatic shower mixers, shower door, shower screen and shower tray have 10-year quarantee and all the riser rails, head/hand showers, hoses, parking bracket and shower shelves have 3-years of guarantee.



BROGRUND shower set with thermostatic

mixer. Head shower Ø200 mm, hand shower Ø90 mm, connection centres 150 mm, length of hose 150 cm.

3-spray hand shower.

203.425.35 Chrome-plated finish



VOXNAN shower set with thermostatic mixer.

Head shower Ø200 mm, hand shower Ø90 mm, connection centres 150 mm, length of hose 150 cm. mm, length of hose 150 cm. 3-spray hand

Chrome-plated finish



BROGRUND head/hand shower kit with

Head shower Ø200 mm, hand shower Ø90 mm, length of hose 150 cm. Single-spray hand shower.


Chrome plated finish 903.425.46



VOXNAN head/hand shower kit with diverter.

Head shower Ø200 mm, hand shower Ø90 mm, length of hose 150 cm. Single-spray hand shower.

Chrome plated finish 503.425.91




BROGRUND riser rail with hand shower kit.

Hand shower Ø90 mm, rail height 65 cm, length of hose 150 cm.

Single-spray hand shower.

Chrome plated finish 103.425.45



VOXNAN riser rail with hand shower kit. Hand shower Ø90 mm, rail height 65 cm, length of hose 150 cm.

Single-spray hand shower.

Chrome plated finish 703.426.13



BROGRUND thermostatic bath/shower mixer. Connection centres 150 mm.

Chrome-plated finish 803.425.42



VOXNAN thermostatic shower mixer.

Connection centres 150 mm.

Chrome-plated finish 603.426.04



BROGRUND thermostatic shower mixer.

Connection centres 150 mm.

Chrome-plated finish 403.425.39



VOXNAN 3-spray hand shower. Hand shower

Chrome-plated finish 203.425.78



BROGRUND single-spray hand shower. Hand

Chrome-plated finish 003.425.41



VOXNAN shower shelf, 25×13×4 cm. Fits on shower rails and poles 19-25 mm in diameter, mounted at a minimum distance of 58 mm from

Chrome-plated finish 703.285.89



BROGRUND 3-spray hand shower. Hand shower

Chrome-plated finish 403 425 44



BROGRUND shower shelf, 25 cm×11×4 cm. Fits on shower rails and poles 19-25 mm in diameter, mounted at a minimum distance of 56 mm from

Chrome-plated finish 903.285.26

All parts

All thermostatic shower mixers, shower door, shower screen and shower tray have 10-year guarantee and all the riser rails, head/hand showers, hoses, parking bracket and shower shelves have 3-years of guarantee.



VALLAMOSSE riser rail with hand shower kit. Hand shower Ø80 mm, rail height 62 cm, length of hose 150 cm.

Single-spray hand shower.

Chrome-plated finish 103.496.60



VALLAMOSSE thermostatic shower mixer.

Connection centres 150 mm.

Chrome-plated finish 103.496.55



VALLAMOSSE singe-spray hand shower. Hand shower Ø80 mm.

Chrome-plated finish 203.496.50



LILLREVET shower hose, length 150 cm.

Chrome-plated finish 703.905.62



KOLSJÖN shower hose, length 150 cm.

Chrome-plated finish 603.425.95



KOLSJÖN hand shower parking bracket, 50×50 mm.

Chrome-plated finish 303.905.02

Mixer taps and accessories

All bathroom mixer taps have 10-year guarantee.



BROGRUND tall mixer tap, height 28 cm.

Chrome plated brass 403.430.96



VOXNAN towel rail, chrome plated finish.

43×13 cm	703.340.00		
63×13 cm	603.285.99		



BROGRUND mixer tap, height 17 cm.

Chrome plated brass



VOXNAN wall shelf with towel rail, chrome plated finish.

68×28 cm 103.285.87



BROGRUND towel rail, stainless steel.

47×13 cm	403.340.06
67×13 cm	303.285.34

BROGRUND towel holder 3 bars, extendable

604.267.07



VOXNAN towel holder 3 bars, extendable bars Stainless steel/ chrome-plated zinc 204.345.49



VOXNAN hanger for door, 35.8×11.5 cm.

100	Chrome plated finish	803.285.79
-----	----------------------	------------

Chrome plated finish



BROGRUND hanger for door, 29×14 cm.

Stainless steel

203.285.44



VOXNAN towel hanger, height 16 cm. Chrome plated finish

\/(77NAN ka	ob, 2 pack.		

203.285.82



BROGRUND extendable towel stand, width 124–155 cm, height 84 cm.

Stainless steel 304.089.98



BROGRUND corner wall shelf unit, 19×19×58 cm,

Stainless steel



and shower parking bracket, 50×50 mm.



BROGRUND hook, 2 pack.

Stainless steel 603.285.42



VOXNAN tall mixer tap, height 30 cm.

Chrome plated brass 003.430.60



VOXNAN mixer tap, height 18 cm.

Chrome plated brass 704.430.90

Services

We offer a range of services to help you with everything from putting it together to getting it home. Of course, the more you do yourself, the lower the price will be. And the more we do for you, the more you can sit back and relax!

Delivery service

Add our delivery service to your total cost regardless of whether you're shopping online or in your local store. We can deliver the same day/next day within the store delivery area. And, we don't just stop at your front door, we deliver all the way to your room of choice.

Assembly service

We assemble your IKEA furniture in your home following the assembly instructions. The assembly service includes disposal of all packaging in an environmentally friendly way.

It's ok to change your mind

You have 365 days to return your purchase. Keep your receipt safe to make returns easier. You're free to change your mind. Return unused items in their original packaging within 365 days together with proof of purchase for a full refund.

