

# TILLREDA

GB


GR



Design and Quality  
IKEA of Sweden

**ENGLISH**  
**ΕΛΛΗΝΙΚΑ**

**5**  
**6**






1x




1x



1x





1


A hand is shown turning the top knob clockwise. An arrow indicates the direction of rotation. The knob is currently pointing to the 'Med' position. The 'Min' and 'Max' positions are also labeled.

2


A hand is shown turning the middle knob counter-clockwise. An arrow indicates the direction of rotation. The knob is currently pointing to the 30 mark. The 0, 1, 2, 3, 4, and 5 marks are also labeled.

| Min                                                                                 |  | Med                                                                                   | •                                                                                     | Max                                                                                                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>115W</b>                                                                         | <b>230W</b>                                                                         | <b>390W</b>                                                                           | <b>540W</b>                                                                           | <b>700W</b>                                                                                                                                                                                                                                                                                                                                                      |
|  |  |  |  | <br><br><br> |


## Product description



## Control panel



- 1** Power knob
- 2** Timer knob



## Functions

### **1** Microwave power level

Variable power levels add flexibility to microwave cooking. Desired levels can be chosen by turning the power knob.


### **2** Timer

To set the time of cooking by turning the timer knob to desired time per your food cooking guide.

## Specification


|                                 |                            |
|---------------------------------|----------------------------|
| Model:                          | <b>TILLREDA 604.933.58</b> |
| Rated Voltage:                  | 230-240V~ 50Hz             |
| Rated Input Power (Microwave):  | 1050W                      |
| Rated Output Power (Microwave): | 700 W                      |
| Oven Capacity:                  | 20 L                       |
| Turntable Diameter:             | 255 mm                     |
| External Dimensions:            | 439.5x340.0x258.2mm        |
| Net Weight:                     | 10.75 kg                   |

## Περιγραφή προϊόντος




- 1** Γυάλινος δίσκος
- 2** Πίνακας ελέγχου
- 3** Πόρτα
- 4** Κουμπί ανοίγματος πόρτας

## Πίνακας ελέγχου



- 1** Κουμπί λειτουργίας
- 2** Κουμπί χρονοδιακόπτη



## Λειτουργίες

### 1 Επίπεδο ισχύος μικροκυμάτων

Τα διάφορα επίπεδα ισχύος προσφέρουν ευελιξία στο μαγείρεμα στον φούρνο μικροκυμάτων. Μπορείτε να επιλέξετε το επιθυμητό επίπεδο ισχύος περιστρέφοντας το κουμπί λειτουργίας.

### 2 Χρονοδιακόπτης

Για να ρυθμίσετε τον χρόνο μαγειρέματος, περιστρέψτε το κουμπί χρονοδιακόπτη στον επιθυμητό χρόνο, σύμφωνα με τον οδηγό μαγειρέματος.

## Προδιαγραφή

|                                            |                            |
|--------------------------------------------|----------------------------|
| Μοντέλο:                                   | <b>TILLREDA 604.933.58</b> |
| Ονομαστική τάση:                           | 230-240 V ~ 50 Hz          |
| Βαθμονομημένη ισχύς εισόδου (Μικροκύματα): | 1050 W                     |
| Βαθμονομημένη ισχύς εξόδου (Μικροκύματα):  | 700 W                      |
| Χωρητικότητα φούρνου:                      | 20 L                       |
| Διάμετρος περιστρεφόμενου δίσκου:          | 255 mm                     |
| Εξωτερικές διαστάσεις:                     | 439,5×340,0×258,2 mm       |
| Καθαρό βάρος:                              | 10,75 kg                   |



