


BLÅVINGAD



Design and Quality
IKEA of Sweden

**English**

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

English

You can use either rechargeable or non-rechargeable batteries.

Before charging, remove the rechargeable batteries from the toy.

Only use batteries of the same or equivalent type as recommended.

Do not mix old and new batteries.

Follow the correct polarity when you insert the batteries.

Used batteries must be removed from the product.

Do not short-circuit the supply terminals.

עברית

חשוב! קראו בעיון ושמרו לשימוש עתידי.

עברית



באפשרותכם להשתמש בסוללות נטענות או סוללות רגילות שאינן נטענות.

לפני טעינה, יש להסיר את הסוללות הנטענות מהמוצר. השתמשו רק בסוללות מאותו סוג או סוללות בעלות מתח זהה כמומלץ.


אין לערבב סוללות ישנות וחדשות. הקפידו על קוטביות נכונה בעת התקנת הסוללות במוצר.

יש להסיר סוללות משומשות מהמוצר.



אין לקצר את מגעי הסוללה.




1



2




3




4




5







6



7





15 min

