




FÅGELFJÄLLET



Design and Quality
IKEA of Sweden



English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip-over. To reduce the risk of furniture tip-over:

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

Place heaviest items in the lower drawer.

Do not set TVs or other heavy objects on top of this product.

Never let children climb or hang on drawers, doors, or shelves.

Read and follow each step of the instruction carefully.

עברית

אזהרה!



נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית. על מנת להפחית את הסיכון של נפילת רהיטים:



יש להקפיד ולקבע את הריהוט לקיר באמצעות אביזרי קיבוע.




על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:

הניחו את הפריטים הכבדים ביותר במגירה התחתונה. הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.






אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים. קראו ופעלו בזהירות לפי כל שלב בהוראות.









	A	B	C
www.IKEA.com/secure-it			
	Ø 8 mm (5/16")	Ø 8 mm (5/16")	Ø 3 mm (1/8")



2x



2x



2x




2x




4x

1




158568
10127144

4x



100001

1x




10101849
10099967



118331

22x




100217

8x




101345

22x




151707

8x



151708

8x




10093081

12x



10093082

28x



119250

119252

22x



100359

2x




146114

48x

2x

2



10133139

8x




145718

159553


10120234

32x



130449

32x



119976

16x




119030

118224

117434


64x



10040242


48x

8x




10050475
10043622

8x



10133186


2x




10142618

8x


1




2




3




4




5






6






7




8




9




10




11




12




13




14




4x




15




6x




16




17




18




19





20



21




22




23


8x




24




2x




25




26




27




28






30



31






www.IKEA.com/secure-it



www.IKEA.cn/secure-it






32


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית


הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.








33

x





34







33











33









36




37




38




39




40




41




42




43




44





45




46



47





48





1



2

