


FÅGELFJÄLLET



Design and Quality
IKEA of Sweden



English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip-over. To reduce the risk of furniture tip-over:

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

Place heaviest items in the lower drawer.

Do not set TVs or other heavy objects on top of this product.

Never let children climb or hang on drawers, doors, or shelves.

Read and follow each step of the instruction carefully.

עברית

אזהרה!

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית. על מנת להפחית את הסיכון של נפילת רהיטים:

יש להקפיד ולקבע את הריהוט לקיר באמצעות אביזרי קיבוע.

על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:

הניחו את הפריטים הכבדים ביותר במגירה התחתונה.




הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.

אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים. קראו ופעלו בזהירות לפי כל שלב בהוראות.















www.IKEA.com/secure-it

	A	B	C
	Ø 8 mm (5/16'')	Ø 8 mm (5/16'')	Ø 3 mm (1/8'')




1



100214

3x



100217

1x



118331

21x



105248

6x



108098

1x



101345

18x




119250

119251


119252

21x




151708

4x



151707

4x




10093081

14x



10093082

14x




109837

123840


10121196

4x



102553


3x



158568

10127144


3x



10099967

10101849


2x



100001

1x


2




2x




2x




4x



2x




6x




6x




2x




1x




2x



2x



2x




2x




4x

371505




1




2




3




4




5




6




7




8




9




10




11




12




13




14





15




16




17




18




19




20




21




22




23




24




25




26




27




28




29




30





31





32




33





34





35




14x




36






2x






38



x

x






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



40


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm
(5/16")



1




2



34


B





Ø 8 mm
(5/16")



1




2



35


C




Ø 3 mm
(1/8")



1



37



41

x

x

2x



42




x


x


2x

10087223












41







44



4x



45



2x

146856
146857
10123477

