


GETKÅL



Design and Quality
IKEA of Sweden



English

For INDOOR & OUTDOOR USE!

WARNING!

Do not connect the chain to the supply while it is in the packing. The connecting cable can not be repaired or replaced. If the cable is damaged the entire fitting must be discarded.

Do not connect this chain electrically to another chain.

NON-REPLACEABLE BULB.

CAUTION! Strangulation hazard.

Hang out of reach of young children.

ONLY USE A SAFETY TRANSFORMER AS SUPPLY FOR THE PRODUCT.

English

The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

English

For lighting chains which rely on gaskets to provide the specified degree of protection against dust, solid objects and moisture:

WARNING – THIS LIGHTING CHAIN MUST NOT BE USED WITHOUT ALL GASKETS BEING IN PLACE.

עברית

לשימוש ביתי וחיצוני!
אזהרה!

אין לחבר את שרשרת התאורה לחשמל בעודו באריזה. לא ניתן לתקן או להחליף את כבל החיבור. במידה והכבל ניזוק - יש להחליף את כל החיבורים


זהירות! סכנת חנק.
החזיקו את המוצר הרחק מהישג ידם של ילדים קטנים
יש להשתמש אך ורק בשנאי הבטיחות המצורף לאריזת המוצר.

עברית

נורת המנורה אינה ניתנת להחלפה; יש להחליף את המנורה כולה כאשר הנורה מגיעה לסוף חייה.

עברית

האטמים של שרשראות תאורה נועדו לספק רמת הגנה מסוימת מפני אבק, חפצים מוצקים ולחות:
אזהרה - אין להשתמש בשרשרת תאורה זו מבלי שכל האטמים יהיו מאובטחים כראוי.



1

