


GREJSIMOJS



Design and Quality
IKEA of Sweden



English

IMPORTANT SAFETY INSTRUCTIONS

For indoor use only.

Regularly check the cord, the transformer and all other parts for damage. If any part is damaged the product should not be used.

Important information! Keep these instructions for future use.

English

Not recommended for children under 3 years of age. The transformer is intended for adult use only, keep out of reach from children.

As with all electric products, precautions should be observed during handling and use to prevent electric shock.

English

This product contains a light source of energy efficiency class F.

עברית

הוראות בטיחות חשובות
מיועד לשימוש ביתי בלבד.

בדקו באופן קבוע את הכבל, השנאי וכל שאר החלקים על מנת לוודא כי לא ניזוקו. במידה ונמצא כי חלקים מסוימים ניזוקו, אין להשתמש במוצר. מידע חשוב! שמרו הוראות אלה לעיון בעתיד.



עברית

אינו מומלץ לילדים מתחת לגיל 3. השנאי מיועד לשימוש על ידי מבוגר בלבד, יש להרחיק מהישג ידם של ילדים.


כמו בכל מוצר חשמל, יש לנקוט באמצעי זהירות במהלך השימוש והטיפול למניעת התחשמלות.

עברית


מוצר זה כולל מקור אור בעל דירוג אנרגטי F.












1



2












**English**

Replacing the light source: Only use a GUZ 5.3 LED light source. Only to be replaced by an adult.

עברית

החלפת מקור האור: יש להשתמש רק בנורת לד GUZ 5.3 .
ההחלפה תתבצע על ידי מבוגר בלבד.





1 + 2		
006.035.24 906.035.29	10056114	144647
506.035.26 106.035.33	10056114	144650
506.035.31 606.035.21	10056114	10077901
106.035.28	10056114	10077902
406.035.22	10056114	144650
706.035.25	10056114	144651
206.035.23	10124148	144652
306.035.27	10124148	144653

