



GULLABERG



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית


אזהרה


נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.


יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.




על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת הרהיטים:



- מקמו את הפריטים הכבדים ביותר במגירה התחתונה.
- הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.
- אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.












1



118331

12x




101345

20x



146114


4x



112357

10053816

4x



107091


1x



10051650

10051660

4x



10039878

2x




119251

119252


12x

2



145718

2x




10097181
10097180

2x



118331

2x



106603

2x




146114

4x




101345

2x




131361

4x




109048

1x




121714

1x



107967

1x




109049

1x




100823

2x





1





4x

IKEA CL

IKEA CR




2




8x

118331




3




12x

101345



4




5




6




7




8




9







10




11




12




13




14




15




16




17



18





19


English


The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


עברית


הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm (5/16") 


1 


2  70 mm (2 3/4")


3 


B




Ø 8 mm (5/16") 


1 


2  ≈ 30 mm (≈ 1 1/4")


3 


C






Ø 3 mm (1/8") 

1 


2  ≈ 30 mm (≈ 1 1/4")

3 


20




21




22




23







24









25










28




29




30




31




32




33




34



35




36




0

37



38



39

