


GULLABERG



Design and Quality
IKEA of Sweden



English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip over. To prevent tip over this furniture must be used with the wall attachment device(s) provided.

Screw(s) and plug(s) for the wall are not included. Use screw(s) and plug(s) suitable for your walls. If you are uncertain, seek professional advice. Read and follow each step of the instruction carefully.

עברית

אזהרה!






נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.






על מנת למנוע את נפילת הרהיט, יש לקבע אותו לקיר באמצעות אבזרי הקיבוע הכלולים באריזה.

הברגים לקיבוע אינם כלולים מכיוון שיש להתאים אותם לחומר ממנו עשוי הקיר המיועד. לקבלת מידע נוסף על הברגים המתאימים לקיבוע, אנא פנו לאיש מקצוע. קראו ופעלו לפי ההוראות המפורטות בהירות.










1



16x




4x




12x




22x




24x




4x




3x




2x




4x



4x




1x



2x




2x




2x

2



151930

12x




120076

16x




10095420

8x



106603


6x



10095978

10096248


6x



10121157



10121566

4x





155073



1x




2




3




4




5




6




7






8










10






11




12




13








14





15








17




18




19



20








www.IKEA.com/secure-it



www.IKEA.cn/secure-it

22







English




The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית





הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.










24




25




26




27




28




29




30




31







32




33




34




35



36



37



38

