




HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.



יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.



על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:



מקמו את הפריטים הכבדים ביותר במגירה התחתונה.





הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.






אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.











109048

2x



10087223

2x




109049

1x




100823

2x



10102070


1x



106989


1x

1



120173

4x



101359

2x



101345

13x



146114

1004962

18x



10047146


10047130

2x




10093082

12x



10093081


12x



151706

151708


6x



151705

151707


6x



153548

158568

2x



10040039


10051022

2x



10050771

2x



10050769

2x

2




144575

8x



144574

8x



10049270


2x

A



118331

12x




119976

6x



146114

18x



145718


159553

12x



101345


10x



119030


118224

24x




10052019

6x





10040242

3x




1







3




4




5




6




7




8




9






10






11




12




13




14




15




16







17





18




19











22






23




24








25



26






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



27


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm
(5/16")



1




2




70 mm
(2 3/4")

3




B




Ø 8 mm
(5/16")



1




2




≈ 30 mm
(≈ 1 1/4")

3




C



Ø 3 mm
(1/8")



1





2






≈ 30 mm
(≈ 1 1/4")


3












28












27















31





32



33







2x




34




35




36




37




38



39



40



41

