




HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.



יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.



על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:



מקמו את הפריטים הכבדים ביותר במגירה התחתונה.




הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.




אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.












1




101345

14x




151706
151708

10x



151705
151707

10x



10093081

6x




10093082

6x




146114

36x



153548
158568


2x



10040039
10051022


4x

A



118331

24x




119976

12x



146114

36x



145718

24x



101345

20x




119030

118224


120076

48x




10052019

12x




10040242

6x




109572

2x



10087223



2x




10102070

2x


370172




2




3




4




5




6




7




8




9




10




11




12




13









15







16






17



18

X

X






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



19


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm
(5/16")



1




2




70 mm
(2 3/4")

3



B




Ø 8 mm
(5/16")



1




2




≈ 30 mm
(≈ 1 1/4")

3




C



Ø 3 mm
(1/8")



1





2







≈ 30 mm
(≈ 1 1/4")









3









20















23




24




25





2x





4x




26


27




28




29




30




31





32




33



34




35






1



2



3

