




HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.



יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.



על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:



מקמו את הפריטים הכבדים ביותר במגירה התחתונה.




הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.






אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.













106989

2x



109048

2x



121714

2x



109049


2x



100823


4x

1



120173

4x



101345

9x




146113
10049062

2x



146114

18x




10093081

14x




10093082

14x




151706
151708

14x




151705
151707

14x




153548
158568

2x



10040039
10051022

2x




10042365
10044438

2x


2



8x



8x




2x

A




12x




6x




18x




12x




10x




24x





6x




3x




1




2




3




4




5




6





7




8




9




10






11









12




13









14








15




16







17




18




2x





19




20







21




22




23




24




25





26






27





28








www.IKEA.com/secure-it



www.IKEA.cn/secure-it



30

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.

A

Ø 8 mm
(5/16")

1

2

70 mm
(2 3/4")

3

B

Ø 8 mm
(5/16")

1

2

≈ 30 mm
(≈ 1 1/4")

3

C

Ø 3 mm
(1/8")


1

2


≈ 30 mm
(≈ 1 1/4")



3

31





32






33


33




34




34





35



35







2x




36




37




38




39




40




41



42



43



44

