




HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה



נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.



יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.



על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:




מקמו את הפריטים הכבדים ביותר במגירה התחתונה. הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.





אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.













2




159553
145718

4x



118331

4x




119976

2x



101345

6x




119030
118224

8x




146114

6x



10040242


1x



10052019

2x

1




119976

2x



101345

16x




10093081

6x




10093082

6x



151707

14x



151708

14x



144574


4x

10051084




146114

6x



10052019

2x



133303

190586


2x



10051650

10051660


20x



10050715

10042135


4x



153548

158568


4x



10051022


10040039

4x





10039873

4x




10039878


4x




1




2




3




4




5




6




7




8




9




10




11




12




13




14




15





16




17






↓
18



19






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



22


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). לקבלת מידע נוסף על הברגים והדיבלים המתאימים לקיבוע, אנא פנו לאיש מקצוע.


A




Ø 5/16"
(8 mm)




1




2



3




B




Ø 5/16"
(8 mm)




1




2



3




C




Ø 1/8"
(3 mm)



1





2







3









23







23








24




25




26







27




28




29






4x




10042135
10050715


144574
10051084




31




32




33




34




35







36



37





38




39


40




41



42



43



44

