


HAVSTA



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using the tip-over restraints provided.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.



יש להקפיד ולקבע את הריהוט לקיר באמצעות אביזרי קיבוע המצורפים.



על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת הרהיטים:




מקמו את הפריטים הכבדים ביותר במגירה התחתונה.





הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.

אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.










2x




2x



2x




4x



2x

1




100214

2x




109540

7x



139615

4x



118331

21x



113434


122332

25x




101350

24x



117186

24x



100092

1x

2



118331

8x




113434

8x



101350

8x




144574

10x



144575

10x




159991

159992


10101154

2x



153549

2x



108255


5x

3




194867

6x



10091382

6x




139615

24x



110630

24x




10095420

24x




119030

24x




101345



20x




10040242

4x







3




4




5




6




7




8




9




10





11




12




13





14




15




16




17




18




19




20




21




22




24




25




26




27




28




29




30





31







32




33





34







35




36



37

x

x






www.IKEA.com/secure-it



www.IKEA.cn/secure-it




38

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.




Ø 8 mm
(5/16") 



1



2




3




Ø 8 mm
(5/16") 



1



2




3




Ø 3 mm
(1/8") 


1




2




39








40





41









42








43

44








↕
45




46




47




48






49




50




51




52



53



54



55

