


IDANÄS



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.

יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.




על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:






- מקמו את הפריטים הכבדים ביותר במגירה התחתונה.
- הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.
- אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.












2x

106989




109049

2x




100823

4x



109048

2x




121714

2x



14

1



100219

6x



118331
112996

14x



119253
118137

14x





101350

14x




131399
157732

4x




100001

1x




100002

1x




104171

8x




10044657

2x



112805

2x






10042565
115309

1x




9


1




2




3




4




5




6




7




8




9








10






11















16


17





↓
18








www.IKEA.com/secure-it



www.IKEA.cn/secure-it



20


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm
(5/16")



1




2




70 mm
(2 3/4")

3




B




Ø 8 mm
(5/16")



1




2




≈ 30 mm
(≈ 1 1/4")

3




C



Ø 3 mm
(1/8")



1




2





≈ 30 mm
(≈ 1 1/4")

3









23

