



IDANÄS



Design and Quality
IKEA of Sweden



English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip over. To prevent tip over this furniture must be used with the wall attachment device(s) provided.


The screw(s) and plug(s) supplied can be used with most solid and hollow walls. For solid wood use the screw(s) without plug(s). Use screw(s) and plug(s) suitable for your walls. If you are uncertain, seek professional advice. Read and follow each step of the instruction carefully.


עברית


אזהרה!






נפילת רהיטים עשויה לגרום לפגיעה גופנית חמורה. על מנת למנוע נפילת רהיטים, יש לקבע אותם לקיר באמצעות אבזרי הקיבוע הכלולים באריזה.





הברגים לקיבוע אינם כלולים מכיוון שיש להתאים אותם לחומר ממנו עשוי הקיר. השתמשו בציווד המתאים לקירות בביתכם. מומלץ להתייעץ עם איש מקצוע או לפנות לחנות מתמחה. קראו ופעלו לפי ההוראות המפורטות בזהירות.













1




10093458

4x



100214

1x




157732
131399

5x



100212

1x



102553

4x




100347

8x



101352

9x




10093081

4x




10093082

4x



151708

6x



151707

6x




144575

8x




144574

8x




131398

1x



10075401
10043847

8x




100001

1x




10

2



10047244

6x



119976

4x







10041120

4x




32




121714

150689

2x




2x




150688

2x



2x

10079637
10005905




126916

2x




147968

2x




25


1




2




3




4




5




6









7




8









13




14




15




16





17




18













22




23




24




25



26




27



28

×

×






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.

A

**Ø 8 mm
(5/16")**

1

2

70 mm
(2 3/4")

3

B

**Ø 8 mm
(5/16")**

1

2

≈ 30 mm
(≈ 1 1/4")

3

C


**Ø 3 mm
(1/8")**

1


2

≈ 30 mm
(≈ 1 1/4")


3







30






31




32




33





34




35




36



37



38



39

