





KILBERGET



Design and Quality
IKEA of Sweden



English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip-over. To reduce the risk of furniture tip-over:

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

Place heaviest items in the lower drawer.

Do not set TVs or other heavy objects on top of this product.

Never let children climb or hang on drawers, doors, or shelves.

Read and follow each step of the instruction carefully.

עברית

אזהרה!

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית. על מנת להפחית את הסיכון של נפילת הרהיטים:



יש להקפיד ולקבע את הרהיט לקיר באמצעות אביזרי קיבוע.



על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת הרהיטים:



הניחו את הפריטים הכבדים ביותר במגירה התחתונה.




הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.




אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים. קראו ופעלו בזהירות לפי כל שלב בהוראות.












1



100214

10x



118331

26x




101345

40x



146114

30x




153552

4x



119030


26x



100001


1x

2




145718

16x



118331

16x




109563

10x



101345

10x



10099670

10x




119030

32x




146114

30x



10040242

5x




10101009

1



14x



101345




2

8x


118331




3




4




5




6




7




8




9




10




11





12




13




14




15




16




17





18




19




20




21





22






24




25

×

×






English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.




Ø 8 mm
(5/16")

- 1**
- 2** 70 mm
(2 3/4")
- 3**





Ø 8 mm
(5/16")

- 1**
- 2** ≈ 30 mm
(≈ 1 1/4")
- 3**





Ø 3 mm
(1/8")

- 1**
- 2** ≈ 30 mm
(≈ 1 1/4")
- 3**





26







27








28







↓
28









30




31




32




33




34




35




36




37





38




39




40







41




42




43




44




45



46




47




48

4x




49



4x



50



51



52



53

