



KOPPANG



Design and Quality
IKEA of Sweden



English

WARNING!

Children have died from furniture tip over. To prevent tip over this furniture must be used with the wall attachment device(s) provided.


The screw(s) and plug(s) supplied can be used with most solid and hollow walls. For solid wood use the screw(s) without plug(s). Use screw(s) and plug(s) suitable for your walls. If you are uncertain, seek professional advice. Read and follow each step of the instruction carefully.


עברית


אזהרה!






נפילת הרהיט עלולה לגרום לפגיעה גופנית קשה או קטלנית. על מנת למנוע את נפילת הרהיט יש לקבע ריהוט לקיר באמצעות ערכת קיבוע המצורפת.





הברגים והדיבלים הכלולים מתאימים לרוב הקירות המוצקים והחלולים. עבור עץ מלא השתמשו בברגים ללא דיבלים. יש להתאים את הברגים והדיבלים לחומר שממנו עשויים קירותכם. לקבלת מידע נוסף על הברגים והדיבלים המתאימים לקיבוע, אנא פנו לאיש מקצוע. קראו ופעלו בהירות לפי כל שלב בהוראות.













1




101354

2x




115980

2x




149825

6x




118331
112996

22x



101350

26x




119030
117434

22x




100365

32x




100006

1x



153552
158590

6x



101221

2x



11


2




24x




12x



24x




24x




12x




12x




48x



36




2x




2x



4x




2x



2x





28



[illegible]

158933









2

3x


158933




3




4




5




6




7




8




9




10



11




12







3x


158933





3x



158933














18




19




20




21




22




23




24




25




26




27







28







326949





28




326949




29




30




31




32



33




34



35

x






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



36


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm
(5/16")



1




2




70 mm
(2 3/4")

3




B




Ø 8 mm
(5/16")



1




2




≈ 30 mm
(≈ 1 1/4")

3




C




Ø 3 mm
(1/8")



1




2









≈ 30 mm
(≈ 1 1/4")


3









41




42





43






44




45



46



47



48

