


LASTARE



Design and Quality
IKEA of Sweden



English

WARNING!

Children have died from furniture tipover.

To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

Read and follow each step of the instruction carefully.

עברית

אזהרה!

ילדים נהרגו כתוצאה מנפילת רהיטים.

על מנת להפחית את הסיכון של נפילת רהיטים:

תמיד יש להתקין את אבזר הקיבוע.

לעולם אל תניחו טלוויזיה על מוצר זה.

לעולם אל תאפשרו לילדים לעמוד, לטפס או להיתלות על המגירות, הדלתות או המדפיים.

פתחו אך ורק מגירה אחת בכל פעם.



יש למקם את הפריטים הכבדים ביותר במגירות התחתונות.




קראו ופעלו בזהירות לפי כל שלב בהוראות.












	A	B	C
 www.IKEA.com/secure-it			
	$\text{Ø } 8 \text{ mm (5/16")}$ 	$\text{Ø } 8 \text{ mm (5/16")}$ 	$\text{Ø } 3 \text{ mm (1/8")}$ 






8x



8x




2x



2x




2x




8x



12x




12x




4x



4x




2x




2x




4x




1x




1x




6x




1x




2x



2x




2x






2x







2x




2x




1




2





3







4




5




6




7




8




9




10




11




4x




119252




12




12x





10095326







10095315






13








14





15






13








14





15





16






↓
17







18

2x







↓
16



17



18






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



19

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.

A

\varnothing 8 mm (5/16")

1

70 mm (2 3/4")

2

29

B

\varnothing 8 mm (5/16")

1

\approx 30 mm (\approx 1 1/4")

2

30


C

\varnothing 3 mm (1/8")


1

\approx 30 mm (\approx 1 1/4")


32





20




21








20






21









20







22














↓
22




23















24



25







27

