


# LYSEKIL



Design and Quality  
IKEA of Sweden

## English

The edges of the wall panel may splinter while being sawn. For as clean a cut as possible, saw the wall panel with the front downwards.

IMPORTANT! Adhesive to fix panels to the wall is not supplied. Make sure you choose an adhesive or fixing material that is strong enough and is suitable for the surface of the wall in question: for example, silicone. Different walls have different surface structures, so it is important to adapt the amount of fixing material you use to the type of wall you are covering. If you are unsure, contact your local specialist retailer.

After the panels have been fitted in place, seal with silicone to prevent the penetration of any moisture.

Bear in mind that subsequent removal of the wall panels can result in damage to the wall.

## עברית

קצוות פנל הקיר עלולים להתפצל בעת הניסור. לתוצאות הטובות ביותר, נסרו את הפנל כאשר חזיתו מופנית כלפי מטה.




חשוב! האריזה אינה כוללת דבק להדבקת הפנלים לקיר. בחרו את הדבק המתאים לשטח הפנים של הקיר: לדוגמא, סיליקון. חשוב להתאים את כמות החומר המשמש להדבקה לסוג שטח הפנים של הקיר. אם אינכם בטוחים, מומלץ להתייעץ עם איש מקצוע או חנות חומרי בניין.





לאחר הדבקת הפנלים, אטמו את הרווחים בעזרת סיליקון כדי למנוע חדירת לחות.


זכרו: בעת הסרת פנלים מודבקים, עלול לגרום נזק לקיר.














1




2




3




4



5



6



7

