




MALM



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.



יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.



על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:



מקמו את הפריטים הכבדים ביותר במגירה התחתונה.


הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.

אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.












Ø 8 mm (5/16'')	Ø 8 mm (5/16'')	Ø 3 mm (1/8'')


--	--

--	--



114334

4x




101353

2x



101345

2x



110519

4x



118331

2x




100349

4x




109558

2x



110630

2x



10003193

3x




109560

3x



105344

2x




122998

4x




114254

4x




153548

4x




113453


1x




326949




118250




1




2




3





4




5




6




7




8






10



11






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



12


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




**Ø 8 mm
(5/16")**



1




2




70 mm
(2 3/4")

3




B




**Ø 8 mm
(5/16")**



1




2




≈ 30 mm
(≈ 1 1/4")

3



C




**Ø 3 mm
(1/8")**


Ø 3 mm
(1/8")



1




2




≈ 30 mm
(≈ 1 1/4")

3







14




15




16




17




18




19





20



21







23

