
# **PRAKTSPIREA**







# **English** For indoor use only.

# **English**

The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

## English

This product is not intended for children due to the content of electrical components. IKEA recommends that only adults should handle the recharging. Regularly examine for damage of cord, plug, enclosure and other parts. In the event of such damage, the product must not be used with the charger. Only to be supplied at SELV.

# Enalish

Only use batteries that are intended for the product. Do not mix old and new batteries, different brands or types.

#### עברית

מתאים לשימוש בתוך הבית בלבד.

#### עברית


נורת המנורה אינה ניתנת להחלפה; יש להחליף את המנורה כולה כאשר הנורה מגיעה לסוף חייה.


## עברית


מוצר זה אינו מיועד לילדים בשל תכולת הרכיבים החשמליים. איקאה ממליצה כי ההטענה תתבצע על-ידי מבוגר בלבד. בדקו בקביעות נזק לכבל, תקע, מאר, וחלקים אחרים. במקרה של נזק כזה, אין להשתמש במוצר עם המטען. שימוש במתח בטיחות נמוך מאוד בלבד.


# עברית


השתמשו רק בסוג הסוללה שצוין עבור מוצר זה. אין לערבב סוללות ישנות וחדשות או סוללות מסוגים או מותגים שונים.
















**English** 

Rechargeable batteries are sold separately. IKEA recommends LADDA rechargeable battery HR03 AAA 1.2V 750mAh, 3 pieces required. עברית

סוללות נטענות נמכרות בנפרד. IKEA ממליצה על סוללות נטענות LADDA מסוג HR03 AAA 1.2V 750mAh נדרשות 3 סוללות.

