


RÅDMANSÖ



Design and Quality
IKEA of Sweden



English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip-over. To reduce the risk of furniture tip-over:

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.
- Read and follow each step of the instruction carefully.

עברית

אזהרה!

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית. על מנת להפחית את הסיכון של נפילת הרהיטים:

יש להקפיד ולקבע את הריהוט לקיר באמצעות אביזרי קיבוע.




על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת הרהיטים:






- הניחו את הפריטים הכבדים ביותר במגירה התחתונה.
- הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.
- אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.
- קראו ופעלו בהירות לפי כל שלב בהוראות.













10115683


1




1x




12x



4x




4x




4x



12x



20x




20x




22x




26x




4x



1x




2x




22x

2




159553

16x



119976

1x



10109447

1x



117434

16x




108528

4x




10047245

24x




10094662

4x




190459

1x




10094656

2x





10094681


2x




10040242

6x







1




2




3



4




5



10120564


4x



6




10121698




10114605


4x




7




8




9




10




11





12




13




14




15




16




17




18




19




20



21



22






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



23


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




**Ø 8 mm
(5/16")**



1




2




70 mm
(2 3/4")

3




B




**Ø 8 mm
(5/16")**



1




2




≈ 30 mm
(≈ 1 1/4")

3




C




**Ø 3 mm
(1/8")**



1



2




≈ 30 mm
(≈ 1 1/4")


3




24





25




26




27




28




29




30




31





32






33




34




35




36




37










38




39




40



41




42






43

6x




44








46



47







50

