

SKATGÅS



Design and Quality
IKEA of Sweden



English

For indoor use only.

English

ALWAYS REMOVE THE BATTERIES BEFORE STORING.

English

The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

English

This product is not intended for children due to the content of electrical components. IKEA recommends that only adults should handle the recharging. Regularly examine for damage of cord, plug, enclosure and other parts. In the event of such damage, the product must not be used with the charger. Only to be supplied at SELV.

English

Only use batteries that are intended for the product. Do not mix old and new batteries, different brands or types.

עברית

מתאים לשימוש בתוך הבית בלבד.

עברית

הקפידו להוציא את הסוללות לפני האחסון.

עברית



נורת המנורה אינה ניתנת להחלפה; יש להחליף את המנורה כולה כאשר הנורה מגיעה לסוף חייה.

עברית




מוצר זה אינו מיועד לילדים בשל תכולת הרכיבים החשמליים. איקאה ממליצה כי ההטענה תתבצע על-ידי מבוגר בלבד. בדקו בקביעות נזק לכבל, תקע, מארז וחלקים אחרים. במקרה של נזק כזה, אין להשתמש במוצר עם המטען. המוצר יוזן במתח בטיחות נמוך מאד (SELV) בלבד.

עברית

השתמשו רק בסוג הסוללה שצוין עבור המוצר זה. אין לערבב סוללות ישנות וחדשות או סוללות מסוגים או מותגים שונים.



1



**English**

4 rechargeable Ni-MH 400mAh
2/3AAA 1.2V battery included.

עברית

כולל 4 סוללות נטענות מסוג Ni-MH
.400mAh 2/3AAA 1.2V

