


SKRUVBY



Design and Quality
IKEA of Sweden



English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip over. To prevent tip over this furniture must be used with the wall attachment device(s) provided.


Screw(s) and plug(s) for the wall are not included. Use screw(s) and plug(s) suitable for your walls. If you are uncertain, seek professional advice. Read and follow each step of the instruction carefully.


עברית





אזהרה! נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.





על מנת למנוע את נפילת הרהיט, יש לקבע אותו לקיר באמצעות אבזרי הקיבוע הכלולים באריזה.

הברגים לקיבוע אינם כלולים מכיוון שיש להתאים אותם לחומר ממנו עשוי הקיר המיועד. לקבלת מידע נוסף על הברגים המתאימים לקיבוע, אנא פנו לאיש מקצוע. קראו ופעלו לפי ההוראות המפורטות בהדירות.










150689

2x



126916

2x



150688

2x




147968

2x



158469

2x




121714

2x



17

327495



145718

4x




10047135

12x



118331

4x




101345

14x




10075382
10051660

16x



10115587
10117010

4x



10078589
10069936

8x



119030

8x




100400

6x




146114

10x




152676

5x



133304
133303

2x




10093081

22x




10093082

22x




104663

3x



10071303

4x





10040242





1x

130417


3x




2




3




4







5






6




4x




7




8





9





10




11





4x





12






2x





13





14







15








18



19






www.IKEA.com/secure-it



www.IKEA.cn/secure-it






19






English


The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית



הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.









21



22




2x




133303
133304

23




16x


10051660
10075382





24





25














29




30




31







32




33




34




35




36




37



38



39



40

