



SMÅSTAD



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה


נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.


יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.


על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים: מקמו את הפריטים הכבדים ביותר במגירה התחתונה.




הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.


אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.












1



114929

6x



116637

6x



110837

4x




102533

8x




102509

2x




100215

4x



130449

14x



159945

6x




152529

6x




109546

4x



151599

4x




100001

1x


2




2x




4x




2x




2x




2x




9x






2x





2x





1x







1




2




3




4




5




6




7





8




9




2x




20




1




2




3




4




5




6




7




8




9





10






11








12






13







15



16








www.IKEA.com/secure-it



www.IKEA.cn/secure-it






18

English



The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית



הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.




19




20




21





22




23







⇅
24




25





26










24












1





2

