




SOLVINDEN







Design and Quality
IKEA of Sweden




1





2








**English**

ALWAYS REMOVE THE BATTERIES BEFORE
STORING.

עברית

הקפידו להוציא את הסוללות לפני האחסון.



English

After approximately 2 years, the rechargeable battery needs to be replaced when the lamp doesn't light up. Replace only with Ni-MH rechargeable 1.2V, 750mAh, AAA type batteries. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

SAVE THESE INSTRUCTIONS FOR FUTURE USE.

עברית

לאחר כשנתיים, יש להחליף את הסוללות הנטענות כאשר המנורה אינה נדלקת. יש להחליף אך ורק בסוללות Ni-MH נטענות, 1.2V, 750mAh, AAA. מקור האור אינו ניתן להחלפה; לכן, כשמקור האור יגיע לסוף תוחלת חייו, יהיה עליכם להחליף את המנורה כולה. שמרו הוראות אלה לשימוש עתידי.

