





STORKLINTA




Design and Quality
IKEA of Sweden



www.IKEA.com/secure-it


A



Ø 8 mm
(5/16")




B



Ø 8 mm
(5/16")







C




Ø 3 mm
(1/8")






106989

1x



10087223

1x



109568

1x



109049






1x





100823


2x

1



2







2x

10103402
10107508
10060250


1




2




3




4




5




6




7




8




9




10






12



13






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



14

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.

A

Ø 8 mm (5/16")

1

2 3/4" (70 mm)

2

16

B

Ø 8 mm (5/16")

1

≈ 1 1/4" (≈ 30 mm)

2

17


C

Ø 3 mm (1/8")


1

≈ 1 1/4" (≈ 30 mm)


18





15





16







16







15









18




19




20







22



23



24



25

