


STRÅLA



Design and Quality
IKEA of Sweden

**English**

FOR INDOOR USE ONLY

English

ALWAYS REMOVE THE BATTERIES
BEFORE STORING.

English

The external flexible cable or
cord of this luminaire cannot be
replaced; if the cord is damaged,
the luminaire shall be destroyed.

English

CAUTION! Strangulation hazard.
Hang out of reach of young
children.

English

Only use batteries that are
intended for the product. Do
not mix old and new batteries,
different brands or types.

עברית

לשימוש בתוך הבית בלבד

עברית

הקפידו להוציא את הסוללות לפני
האחסון.

עברית


הכבל המחובר לגוף תאורה זה אינו ניתן
להחלפה; במידה ונגרם נזק לכבל, יש
להשליך את המוצר כולו.

עברית


אזהרה! סכנת חנק. תלו הרחק מהישג
ידם של ילדים.

עברית


השתמשו רק בסוג הסוללה שצוין עבור
מוצר זה. אין לערבב סוללות ישנות
וחדשות או סוללות מסוגים או מותגים
שונים.






1




2



3





English

The timer switches the light off automatically after 6 hours, and switches it back on at the same time next day.

עברית

הטיימר מכבה את האור באופן אוטומטי לאחר 6 שעות ומדליק אותו שוב למחרת באותה השעה.