


STRÅLA

J2542



Design and Quality
IKEA of Sweden

**English**

For indoor use only.

English

ALWAYS REMOVE THE BATTERIES
BEFORE STORING.

English

The light source of this luminaire
is not replaceable; when the light
source reaches its end of life the
whole luminaire shall be replaced.

English

Fire or explosion can result from
the use of the incorrect battery.

English

Keep batteries out of reach of
children and animals.

English

Only use batteries that are
intended for the product. Do
not mix old and new batteries,
different brands or types.

עברית

מתאים לשימוש בתוך הבית בלבד.

עברית

הקפידו להוציא את הסוללות לפני
האחסון.

עברית

נורת המנורה אינה ניתנת להחלפה; יש
להחליף את המנורה כולה כאשר הנורה
מגיעה לסוף חייה.

עברית


אזהרה - שימוש בסוללה מסוג שאינו
מתאים עלול לגרום לפיצוץ או לשריפה.


עברית

הרחיקו את הסוללות מהישג ידם של
ילדים ובעלי חיים.


עברית

השתמשו רק בסוג הסוללה שצוין עבור
מוצר זה. אין לערבב סוללות ישנות
וחדשות או סוללות מסוגים או מותגים
שונים.








1





2



3





English

The timer switches the light off automatically after 6 hours, and switches it back on at the same time next day.

עברית

הטיימר מכבה את האור באופן אוטומטי לאחר 6 שעות ומדליק אותו שוב למחרת באותה השעה.